

技术资料

2082-P | 备用测试盖:7102



产品概述: 2082-P | 备用测试盖: 7102

This spare test lid is for the 7102 Micro-Bath, because, sometimes you need a lid with holes drilled in it, and sometimes you need a lid that is completely sealed. For calibration, it is convenient to drill a pattern of holes into a test lid to keep the bath sealed during calibration for optimal stability, and to ensure probes are properly spaced from one another and go into the bath vertically. However, you also want to have a lid that prevents spilling when you are carrying the bath from the lab or shop to the test site, so we recommend keeping a spare lid to use during testing. That way you can have ideal test conditions and a clean work environment.







2082-P 备用测试盖:7102



Fluke. 让您的工作畅通无阻。