


# Fluke SW90W FlukeView 示波表软件



## 主要特性

- For ScopeMeter(R) 190 Series II and 120 Series
- Windows XP/Vista/Windows 7/Windows 10
- Requires one free RS-232 port (COM port) or a free USB-Port
- Requires optional PM9080 RS-232 Adapter/Cable or an optional OC4USB-cable (190C Series, 120 Series)

Note: 190 Series II comes with USB-port and USB-cable included. For 190 Series II no additional hardware is required.

## 产品概述: Fluke SW90W FlukeView 示波表软件

FlukeView-1 software adds PC power to your Fluke ScopeMeter test tool


FlukeView-1 ScopeMeter software helps you get more out of your [ScopeMeter 190 Series II Test Tool](#) by:

- Documenting: Transfer screens, waveforms, and measurement data from the ScopeMeter Test Tool to your PC for printing, or to import data to other programs.
- Archiving: Store and retrieve waveforms with text annotations and create your own library for easy reference and comparison.

- Analysis: Gather valuable measurement data and enable cursor measurement to reveal relationship and conditions.

Extended recording of up to four user-selected measurements help you monitor and analyze slow moving signals and related events. Upload waveforms to the PC and use cursors for detailed measurements. Perform waveform analysis, including analyzing harmonics.

## 型号



Fluke SW90W

FlukeView 示波表软件



Fluke. 让您的工作畅通无阻。

福禄克测试仪器（上海）有限公司 电话：400-810-3435 ©2025 福禄克公司  
07/2025  
北京福禄克世禄仪器维修和服务有限公司 电  
话：400-615-1563 未经许可，本文档禁止修改  
福禄克测试仪器（上海）有限公司上海维修中心 电  
话：021-54402301, 021-54401908分机269  
福禄克测试仪器（上海）有限公司深圳第一特约维修点  
电话：0755-86337229